

RTA

CABINET STORE

December 22, 2024

Primary White Shaker Kitchen Cabinets Price List



Sink base		
Model #	Item	Price
EW-CSF42	Primary White Shaker Corner Sink Front for 42" Space - 27" W	\$130.47
EW-SB30	Primary White Shaker Sink Base Cabinet - 30" W x 34.5" H	\$234.63
EW-SB33	Primary White Shaker Sink Base Cabinet - 33" W x 34.5" H	\$248.55
EW-SB36	Primary White Shaker Sink Base Cabinet - 36" W x 34.5" H	\$255.31
EW-SB42	Primary White Shaker Sink Base Cabinet w/ CS - 42" W x 34.5" H	\$292.91
EW-VSB36	Primary White Shaker Vanity Sink Base - 36" W x 34.5" H x 21" D	\$350.44
EW-VSB42	Primary White Shaker Vanity Sink Base - 42" W x 34.5" H x 21" D	\$388.05
EW-VSB48	Primary White Shaker Vanity Sink Base - 48" W x 34.5" H x 21" D	\$433.56

Filler		
Model #	Item	Price
EW-FF396	Primary White Shaker Fluted Filler - 3" W x 96" H	\$91.00
EW-OLF330	Primary White Shaker Overlay Filler - 3" W x 30" H	\$31.96
EW-OLF336	Primary White Shaker Overlay Filler - 3" W x 36" H	\$37.22
EW-OLF342	Primary White Shaker Overlay Filler - 3" W x 42" H	\$42.86
EW-OLF630	Primary White Shaker Overlay Filler - 6" W x 30" H	\$64.31
EW-F396	Primary White Shaker Filler - 3" W x 96" H	\$50.38
EW-F696	Primary White Shaker Filler - 6" W x 96" H	\$101.14

End panel		
Model #	Item	Price
EW-DWR3	Primary White Shaker Dish Washer End Panel	\$108.30
EW-BPLG4896	Primary White Shaker Back Panel (Long Grain) - 48" W x 96" H x 1/4" Thick	\$177.87
EW-OP3353	Primary White Shaker Oven Cabinet Overlay Panel - 33" W x 55" H	\$133.10
EW-TEP3096	Primary White Shaker Tall End Panel	\$190.64
EW-PSP4896	Primary White Shaker 1/2" Thick Finished Plywood Panel	\$295.56

Model #	Item	Price
EW-RCM8	Primary White Shaker Royal Crown Molding	\$134.24
EW-OCM8	Primary White Shaker Outside Corner Molding	\$23.69
EW-SHOE	Primary White Shaker Shoe Molding	\$19.18
EW-SCM8	Primary White Shaker Shaker Crown Molding	\$63.18
EW-BCM8	Primary White Shaker Large Crown Molding	\$128.98
EW-BEM8	Primary White Shaker Bottom Edge Molding (Narrow Light Rail)	\$64.31
EW-BAM8	Primary White Shaker Batten Molding	\$18.80
EW-FBM8	Primary White Shaker Furniture Base Molding	\$88.74
EW-CM8	Primary White Shaker Traditional Crown Molding	\$63.18
EW-COM8	Primary White Shaker Cove Crown Molding	\$105.67

Blind door

Model #	Item	Price
EW-BB36	Primary White Shaker Blind Base Cab for 36" to 39" Space - 30" W	\$310.60
EW-BB42	Primary White Shaker Blind Base Cab for 42" to 45" Space - 36" W	\$351.96
EW-BB48	Primary White Shaker Blind Base Cab for 48" to 51" Space - 48" W	\$387.30
EW-BW3636	Primary White Shaker Blind Wall Cabinet - 36" W x 36" H	\$248.55
EW-BW3642	Primary White Shaker Blind Wall Cabinet - 36" W x 42" H	\$312.10
EW-BW3630	Primary White Shaker Blind Wall Cabinet - 36" W x 30" H	\$228.53

Pantry

Model #	Item	Price
EW-P1884	Primary White Shaker Pantry - 18" W x 84" H	\$486.20
EW-P1890	Primary White Shaker Pantry - 18" W x 90" H	\$524.54
EW-P1896	Primary White Shaker Pantry - 18" W x 96" H	\$545.97

Oven

Model #	Item	Price
EW-OC3390	Primary White Shaker Oven Cabinet - 33" W x 90" H	\$788.51
EW-OC3396	Primary White Shaker Oven Cabinet - 33" W x 96" H	\$842.29
EW-OCD337	Primary White Shaker Oven Cabinet Drawer	\$204.19

Deep

Model #	Item	Price
EW-W361824	Primary White Shaker Deep Wall Cabinet - 36" W x 18" H x 24" D	\$217.71
EW-W362424	Primary White Shaker Deep Wall Cabinet - 36" W x 24" H x 24" D	\$253.07

Single door

Model #	Item	Price
EW-W930	Primary White Shaker Single Door Wall Cabinet - 9" W x 30" H	\$93.63
EW-W936	Primary White Shaker Single Door Wall Cabinet - 9" W x 36" H	\$106.03
EW-W942	Primary White Shaker Single Door Wall Cabinet - 9" W x 42" H	\$125.96
EW-W1230	Primary White Shaker Single Door Wall Cabinet - 12" W x 30" H	\$107.55
EW-W1236	Primary White Shaker Single Door Wall Cabinet - 12" W x 36" H	\$121.07
EW-W1242	Primary White Shaker Single Door Wall Cabinet - 12" W x 42" H	\$144.38
EW-W1530	Primary White Shaker Single Door Wall Cabinet - 15" W x 30" H	\$120.32
EW-W1536	Primary White Shaker Single Door Wall Cabinet - 15" W x 36" H	\$138.74
EW-W1542	Primary White Shaker Single Door Wall Cabinet - 15" W x 42" H	\$164.32
EW-W1830	Primary White Shaker Single Door Wall Cabinet - 18" W x 30" H	\$137.99

EW-W1836	Primary White Shaker Single Door Wall Cabinet - 18" W x 36" H	\$157.18
EW-W1842	Primary White Shaker Single Door Wall Cabinet - 18" W x 42" H	\$187.26
EW-W2130	Primary White Shaker Single Door Wall Cabinet - 21" W x 30" H	\$154.17
EW-W2136	Primary White Shaker Single Door Wall Cabinet - 21" W x 36" H	\$175.60
EW-W2142	Primary White Shaker Single Door Wall Cabinet - 21" W x 42" H	\$208.69
EW-VB15	Primary White Shaker Single Door Base Vanity - 15" W x 21" D	\$188.76
EW-VB18	Primary White Shaker Single Door Base Vanity-18"W x 34.5"H x 21"D	\$203.44
EW-B12	Primary White Shaker Single Door Standard Base Cabinet - 12" W	\$185.75
EW-B09	Primary White Shaker Single Door Full Height Base Cabinet - 9" W	\$134.98
EW-B15	Primary White Shaker Single Door Standard Base Cabinet - 15" W	\$202.67
EW-B18	Primary White Shaker Single Door Standard Base Cabinet - 18" W	\$218.48
EW-B21	Primary White Shaker Single Door Standard Base Cabinet - 21" W	\$236.14

Double door

Model #	Item	Price
EW-B24-2	Primary White Shaker Double Door Standard Base Cabinet - 24" W	\$260.95
EW-B27	Primary White Shaker Double Door Standard Base Cabinet - 27" W	\$322.25
EW-B30	Primary White Shaker Double Door Standard Base Cabinet - 30" W	\$331.28
EW-B33	Primary White Shaker Double Door Standard Base Cabinet - 33" W	\$359.84
EW-B36	Primary White Shaker Double Door Standard Base Cabinet - 36" W	\$367.37
EW-V24-2	Primary White Shaker Double Door Vanity - 24" W x 34.5" H x 21"	\$180.10
EW-V27	Primary White Shaker Double Door Vanity - 27" W x 34.5" H x 21"	\$210.20
EW-V30	Primary White Shaker Double Door Vanity - 30" W x 34.5" H x 21"	\$217.71
EW-V33	Primary White Shaker Double Door Vanity - 33" W x 34.5" H x 21"	\$239.16
EW-V36	Primary White Shaker Double Door Vanity - 36" W x 34.5" H x 21"	\$253.81
EW-W2430-2	Primary White Shaker Double Door Wall Cabinet - 24" W x 30" H	\$183.51
EW-W2436-2	Primary White Shaker Double Door Wall Cabinet - 24" W x 36" H	\$213.95
EW-W2442-2	Primary White Shaker Double Door Wall Cabinet - 24" W x 42" H	\$247.04
EW-W2730	Primary White Shaker Double Door Wall Cabinet - 27" W x 30" H	\$204.93
EW-W2736	Primary White Shaker Double Door Wall Cabinet - 27" W x 36" H	\$231.63
EW-W2742	Primary White Shaker Double Door Wall Cabinet - 27" W x 42" H	\$275.24
EW-W3012	Primary White Shaker Double Door Wall Cabinet - 30" W x 12" H	\$95.88
EW-W3015	Primary White Shaker Double Door Wall Cabinet - 30" W x 15" H	\$118.83
EW-W3018	Primary White Shaker Double Door Wall Cabinet - 30" W x 18" H	\$153.42
EW-W3024	Primary White Shaker Double Door Wall Cabinet - 30" W x 24" H	\$188.01
EW-W3030	Primary White Shaker Double Door Wall Cabinet - 30" W x 30" H	\$211.70
EW-W3036	Primary White Shaker Double Door Wall Cabinet - 30" W x 36" H	\$250.80
EW-W3042	Primary White Shaker Double Door Wall Cabinet - 30" W x 42" H	\$297.81
EW-W3315	Primary White Shaker Double Door Wall Cabinet - 33" W x 15" H	\$129.73
EW-W3330	Primary White Shaker Double Door Wall Cabinet - 33" W x 30" H	\$236.14
EW-W3336	Primary White Shaker Double Door Wall Cabinet - 33" W x 36" H	\$269.24
EW-W3342	Primary White Shaker Double Door Wall Cabinet - 33" W x 42" H	\$319.23
EW-W3612	Primary White Shaker Double Door Wall Cabinet - 36" W x 12" H	\$118.83
EW-W3615	Primary White Shaker Double Door Wall Cabinet - 36" W x 15" H	\$132.74
EW-W3618	Primary White Shaker Double Door Wall Cabinet - 36" W x 18" H	\$176.35
EW-W3630	Primary White Shaker Double Door Wall Cabinet - 36" W x 30" H	\$244.80
EW-W3636	Primary White Shaker Double Door Wall Cabinet - 36" W x 36" H	\$287.65
EW-W3642	Primary White Shaker Double Door Wall Cabinet - 36" W x 42" H	\$341.43
EW-W3918	Primary White Shaker Double Door Wall Cabinet - 39" W x 18" H	\$188.01
EW-W3924	Primary White Shaker Double Door Wall Cabinet - 39" W x 24" H	\$226.35
EW-W3624	Primary White Shaker Double Door Wall Cabinet - 36" W x 24" H	\$210.95

Model #	Item	Price
EW-LSB36	Primary White Shaker Lazy Susan Cabinet - 36" W x 24" D	\$664.62

Easy reach

Model #	Item	Price
EW-WER2430	Primary White Shaker Wall Easy Reach Cabinet - 24" W x 24" D x 30" H	\$266.23
EW-WER2436	Primary White Shaker Wall Easy Reach Cabinet - 24" W x 24" D x 36" H	\$282.70
EW-WER2442	Primary White Shaker Wall Easy Reach Cabinet - 24" W x 24" D x 42" H	\$323.73
EW-ER36	Primary White Shaker Easy Reach Base Cabinet - 36" W x 24" D	\$391.80

Drawer base

Model #	Item	Price
EW-DB12-3	Primary White Shaker Drawer Base Cabinet - 12" W	\$280.88
EW-DB15-3	Primary White Shaker Drawer Base Cabinet - 15" W	\$310.60
EW-DB18-3	Primary White Shaker Drawer Base Cabinet - 18" W	\$333.53
EW-DB21-3	Primary White Shaker Drawer Base Cabinet - 21" W	\$356.84
EW-DB24-3	Primary White Shaker Drawer Base Cabinet - 24" W	\$381.28
EW-DB30-3	Primary White Shaker Drawer Base Cabinet - 30" W	\$435.05
EW-VDB12	Primary White Shaker Vanity Drawer Base - 12" W x 34.5" H x 21"	\$275.98
EW-VDB15	Primary White Shaker Vanity Drawer Base - 15" W x 34.5" H x 21"	\$298.55
EW-VDB18	Primary White Shaker Vanity Drawer Base - 18" W x 34.5" H x 21"	\$321.50
EW-VDB21	Primary White Shaker Vanity Drawer Base - 21" W x 34.5" H x 21"	\$359.84
EW-VDB24	Primary White Shaker Vanity Drawer Base - 24" W x 34.5" H x 21"	\$398.20

Wine Rack

Model #	Item	Price
EW-WR3018	Primary White Shaker Wine Rack - 30" W x 18" H x 12" D	\$168.08

Other

Model #	Item	Price
EW-SPRAYCAN	Primary White Shaker Spray Can	\$7.52
EW-TBUNFOOT	Primary White Shaker Bunfoot	\$75.20
EW-TBUNFOOT2	Primary White Shaker Transitional Bunfoot	\$75.20
EW-TKS8	Primary White Shaker Toe Kick	\$16.18
EW-TPOSTP3	Primary White Shaker Turned Post - 3" W x 35.5" H	\$135.37
EW-TPOSTP5	Primary White Shaker Turned Post - 5" W x 35.5" H	\$206.42
EW-TUKIT	Primary White Shaker Touchup Kit	\$5.64
EW-LRM8	Primary White Shaker Traditional Light Rail	\$128.98
EW-SCRIBE	Primary White Shaker Scribe	\$20.30
EW-SHELF1296	Primary White Shaker Shelf - 96" W x 12" D	\$176.35
EW-CORSM	Primary White Shaker Basic Medium Corbel - 10.5" H	\$35.73
EW-CORT	Primary White Shaker Transitional Corbel	\$100.03
EW-CW2430	Primary White Shaker Corner Wall Cabinet - 24" W x 30" H	\$230.13
EW-CW2436	Primary White Shaker Corner Wall Cabinet - 24" W x 36" H	\$258.32
EW-CW2442	Primary White Shaker Corner Wall Cabinet - 24" W x 42" H	\$327.52
EW-CW2736	Primary White Shaker Corner Wall Cabinet - 27" W x 36" H	\$295.17
EW-CW2742	Primary White Shaker Corner Wall Cabinet - 27" W x 42" H	\$350.44
EW-BBP4842	Primary White Shaker Bead Board - 48" W x 42" H x 0.25" D	\$100.03
EW-BCE1596	Primary White Shaker Book Case End - 1.5" W x 96" H x 15" D	\$145.89

